

FIG. 1




FIG. 2




FIG. 3




FIG. 4

Title: IMAGE FORMING APPARATUS  
AND METHOD OF CONTROLLING  
THE APPARATUS

Inventor(s): Fumiharu NAKAYAMA

Serial No. 09/955,307




FIG. 5

FIG. 6

Initial screen

Do you make pre-registration ?

☒ YES

☐ NO

OK

FIG. 7

Select screen for copy mode

☒ Copy mode A

☐ Copy mode B

Next page

Back OK

FIG. 8

Setting screen for input/output screen

Specify size and direction of original document

☒ A4 Longitudinal ☐ A4 Lateral ☐ B5 Longitudinal ☐ B5 Lateral

Specify size and direction of paper

☒ A4 Longitudinal ☐ A4 Lateral ☐ B5 Longitudinal ☐ B5 Lateral

Specify number of sheets of original document

16

Back OK




FIG. 9




FIG. 10





FIG. 11



Menu screen

Basic copy

Pre-registration mode

XX copy

YY copy


Input reservation number.

1 1

Set original document and turn on copy key.

Detailed description: This is a screenshot of a 'Menu screen'. On the left side, there is a vertical list of five menu items: 'Menu screen', 'Basic copy', 'Pre-registration mode', 'XX copy', and 'YY copy'. Each item is enclosed in a rectangular box. To the right of these items is a larger rectangular area. At the top of this area is the text 'Input reservation number.' Below this text are two numeric input fields, each containing the number '1' and having up/down arrow buttons. Below the input fields is the text 'Set original document and turn on copy key.'

FIG. 12



Re-input guide screen

Cancel

Pre-registration mode

Please input correct reservation number.

1 1

Set original document and turn on copy key.

Detailed description: This is a screenshot of a 'Re-input guide screen'. At the top left is the title 'Re-input guide screen' in a box. At the top right is a 'Cancel' button in a box. Below the title is a label 'Pre-registration mode' in a box. To the right of this label is a text prompt 'Please input correct reservation number.' Below the prompt are two numeric input fields, each containing the number '1' and having up/down arrow buttons. Below the input fields is the text 'Set original document and turn on copy key.'

FIG. 13